


<https://www.dji.com/neo/downloads>

This content is subject to change without prior notice.


DJI and DJI NEO are trademarks of DJI.
Copyright © 2024 DJI All Rights Reserved.




1 Scan the QR code for tutorial videos, DJI Fly app, and user manual.
扫描二维码观看教学视频、下载 DJI Fly App、阅读用户手册。




2 Press down to remove the gimbal protector.
按压取下云台保护罩。



3 Charge to activate the Intelligent Flight Battery before using for the first time.
智能飞行电池首次使用需充电激活。




4 Power on/off: Press, then press and hold.
开机 / 关机: 短按一次, 再长按 2 秒以上。



5 Tap **Connection Guide** on the bottom right corner of the home screen in DJI Fly, select the aircraft model, and then follow the on-screen instructions to complete connection and activation.

在 DJI Fly 首页, 点击界面右下角的连接引导, 选择机型, 根据提示完成连接及激活。



6 **Palm Control (Follow Mode by Default)**
 掌上操控 (默认跟随模式)

